# DIGITUS® 5 Port Gigabit Switch, Unmanaged

**DN-80202-1**

**EAN 4016032492900**

**5 port Gigabit Network Switch, Desktop, Metall Housing**

The 5-Port Gigabit Switch from DIGITUS® is perfectly suited for the easy expansion of your network. Thanks to its fanless design, the switch operates completely noise-free and does not require configuration. Each port can be used as a LAN or uplink port, the cable and network speed are detected automatically. The switch also supports the energy saving features IEEE802.3az & Full-Duplex Flow Control IEE802.3x. Real Plug and Play – Just plug in the network cable and get started.

**Fast and easy expansion of your network - Plug and Play**

- Number of ports: 5 x 10/100/1000 Mbps
- Ethernet standards: IEEE802.3 / 802.3u / 802.3ab / 802.3az
- IEEE 802.3x full-duplex flow control
- Backplane: 10 Gbps
- MAC address table: 2K
- Forwarding rate: 148800 pps per port (1000BASE-TX)
- Data transmission rate: 7.44 Mbps
- Auto-MDI/MDIX function
- Transfer method: Store & Forward
- LED indicators: Power, Link/Act
- Power consumption: 3W max
- Operating temperature: 0 °C to +40 °C
- Storage temperature: -10 °C to +70 °C
- Operating humidity: 10% - 90% RH (non-condensing)
- Input voltage external power adapter: 100 - 240 V AC, 50/60 Hz
- Input voltage switch: 5 V DC, 1 A
- Power supply of power adapter: Euro plug Type C (CEE 7/16)
- Plug type device side: Coaxial plug 5.5 mm/2.1 mm
- Power input at device: 5.5 mm jack for coaxial plug
- Dimensions (L x W x H): 92 mm x 69 mm x 25 mm
- Weight: 180 g
- Color: Black

**Attributes**

- Number of ports: 5
- Ethernet speed: Gigabit
- Industrial usage: no
- Installation type: Desktop
- Managed: no
- Number of ports (Uplink): 0
- Outdoorsuitable: no
- PoE (Power over Ethernet): no
- Protection against vanadlism: no
- VLAN: no

**Package contents**

- 1 x 5 Port Gigabit Switch, Unmanaged
- 4 x Rubber feet
- 1 x QIG

**Logistics**

| | Number (pcs) | Weight (kg) | Depth (cm) | Width (cm) | Height (cm) | cm³ |
|---|---|---|---|---|---|---|
| **Packaging Unit Carton** | 20 | 8.50 | 41.50 | 30.50 | 40.00 | 50,630.00 |
| **Packaging Unit Inside** | 1 | 0.43 | 0.00 | 0.00 | 0.00 | 0.00 |
| **Packaging Unit Single** | 1 | 0.43 | 7.00 | 14.00 | 18.90 | 1,852.20 |
| **Net single without Packaging** | 1 | 0.17 | 2.50 | 6.90 | 9.20 | 0.00 |


Druckfehler, Irrtümer und technische Änderungen sind vorbehalten. | Printing errors, falsities and technical changes remain reserved.

**More images:**



**Safety notes**

- This product is intended for indoor use only.
- Read all instructions and follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
- The mains cable, power supply unit or plug for the power supply is damaged or worn;
- Liquid has penetrated the appliance;
- The device has been exposed to rain or water;
- The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH
Auf dem Schüffel 3
Lüdenscheid, Germany
https://www.assmann.com
info@assmann.com


Druckfehler, Irrtümer und technische Änderungen sind vorbehalten. | Printing errors, falsities and technical changes remain reserved.